



# OBD-II Light Sequence

1. **Start the Vehicle First.**

2. **Plug in the OBD-II Module.**

*(OBD Port is located beneath the steering wheel)*



3. **Lights will flash Red a couple of times.** This indicates the scanner is gathering the VIN info from the vehicle.

4. **Lights will start flashing Green.** This indicates the VIN is being scanned and is building the VIN-specific report.

5. **Lights will start flashing Blue and Green.** This indicates the scanner is transferring data via Bluetooth to your phone.

6. **Lights will turn solid Green when scan is completed.**

7. **You can now turn off the car and remove the scanner from the port.**

